

Service Manual

Electronic Organ

SX-EX25/L

(M), (MC), (EN), (EI), (EH), (EB), (EF), (EZ),
(EW), (EP), (EK), (XL), (XR), (XS), (XD), (X), (N)




Photo: SX-EX25

AREAS

(M) U.S.A.	(EK): the United Kingdom
(MC) Canada	(XL): New Zealand
(EN): Norway, Sweden, Denmark, Finland	(XR): Australia
(EI): Italy	(XS): Malaysia, Singapore, South Africa
(EH): Holland	(XD): Saudi Arabia
(EB): Belgium	(X): the Middle East, Indonesia, Hong Kong, the Philippines, Taiwan, Thailand
(EF): France, Austria	(N): Japan
(EZ): Germany	
(EW): Switzerland	
(EP): Spain	

Specifications

KEYBOARD		UPPER MANUAL: 44 KEYS LOWER MANUAL: 44 KEYS PEDAL KEYBOARD: 13 KEYS
UPPER VOICES	POLY	PIANO, E PIANO, HARPSICHORD, GUITAR, JAZZ GUITAR, HAWAIIAN GUITAR, SYNTH PERC, SYNTH BRASS, ACCORDION, CLARINET, ORGAN, TENOR SAX, STRINGS, TROMBONE, BRASS, TAB VOICES: FLUTE 16', 8', 4', 2', PERC 2-2/3', UPPER POLY VOLUME
	SOLO	FLUTE, PAN FLUTE, SYNTH LEAD, CLARINET, ALTO SAX, TROMBONE, TRUMPET, VIOLIN, UPPER SOLO VOLUME
LOWER VOICES	POLY	PIANO, E PIANO, HARPSICHORD, GUITAR, JAZZ GUITAR, SYNTH BRASS, CLAVI, TENOR SAX, ORGAN, BRASS, STRINGS, TAB VOICES: FLUTE 8', 4', 2', LOWER POLY VOLUME
BASS VOICES		BASS 16', 16' + 8', 8', SYNTH, TUBA, ELECTRIC, CHOPPER, ACOUSTIC, BASS VOLUME
ORCHESTRAL CONDUCTOR		UPPER (SOLO, POLY)
EFFECT	SUSTAIN	UPPER, LOWER, BASS
	TREMOLO	UPPER TAB VOICES, LOWER TAB VOICES, TAB TREMOLO: SLOW/FAST
	CELESTE	UPPER POLY, LOWER POLY, UPPER TAB VOICES, LOWER TAB VOICES
GLIDE		FOOT SWITCH
TECHNI-CHORD		ON, CLOSE/PROGRAM. RECORD*
RHYTHM	SELECTOR	MARCH, BALLAD, 8 BEAT, CHA-CHA, RHUMBA, JAZZ WALTZ, WALTZ, TANGO, SHUFFLE, SWING, SALSA, 16 BEAT, DISCO 1, 2, BOSSA NOVA, SAMBA
	CONTROLS	SYNCHRO & BREAK, START/STOP, TEMPO, DRUMS VOLUME
FILL IN & INTRO		1, 2, SOLO
ENDING		ON
PLAY MODE		PCC, FINGERED, MEMORY
BASS & ACCOMP		1/2, MELODIC, ACCOMP VOLUME
ONE TOUCH PLAY		○
TRANSPOSE		CONTROL (G-C-F#)
VOICE SETTING COMPUTER		SET, 1~4, CANCEL
PROGRAM CHORD COMPUTER		PCC, RECORD*, (LOWER KEYBOARD:  ,  ,  ,  ,  ,  ,  ,  ,  ,  ,  ,  ,  ,  ,  ,  ,  ,  ,  ,  ,  ,  ,  ,  ,  ,  ,  ,  ,  ,  ,  ,  ,  ,  ,  ,  ,  ,  ,  ,  ,  ,  ,  ,  ,  ,  ,  ,  ,  ,  ,  ,  , ,

CONTENTS

■ PART I (INTRODUCTION)

SAFETY PRECAUTION.....	I-1
HOW TO ASSEMBLE THE ORGAN.....	I-2
INSTALLATION OF SY-FD3 (OPTION).....	I-3
ARRANGEMENT OF CONTROL PANEL.....	I-4
BASIC FUNCTIONS.....	I-4
DIFFERENCE BETWEEN SX-EX25L AND SX-EX25.....	I-6
CONNECTION TERMINALS.....	I-7
KEYBOARD RANGES.....	I-7
ADJUSTMENT PROCEDURE.....	I-8
PARTS LOCATION.....	I-8
DISASSEMBLY INSTRUCTIONS.....	I-9
PRECAUTIONS BEFORE SERVICING.....	I-11
SYMPTOMS WHICH APPEAR TO BE SIGNS OF TROUBLE.....	I-12
ERROR DISPLAY.....	I-13
MIDI IMPLEMENTATION CHART.....	I-14

■ PART II (SCHEMATIC DIAGRAM)

WIRING CONNECTION DIAGRAM.....	II-1
BLOCK DIAGRAM.....	II-3
MAIN FDCN MAIN, FD CONNECTOR CIRCUIT BOARD.....	II-6
MAIN FDCN MAIN, FD CONNECTOR CIRCUIT DIAGRAM.....	II-11
DP DRUM PERCUSSION CIRCUIT DIAGRAM & CIRCUIT BOARD.....	II-15

CPSL SIDE CONTROL PANEL CIRCUIT BOARD.....	II-17
CPSL SIDE CONTROL PANEL CIRCUIT DIAGRAM.....	II-19
CPL CP CONTROL PANEL LEFT, RIGHT CIRCUIT BOARD.....	II-21
CPL CP CONTROL PANEL LEFT, RIGHT CIRCUIT DIAGRAM.....	II-23
AS HP AMP & POWER SUPPLY, HEADPHONES CIRCUIT DIAGRAM.....	II-25
AS AMP & POWER SUPPLY CIRCUIT BOARD.....	II-27
HP HEADPHONES CIRCUIT BOARD.....	II-29
MKB MANUAL KEYBOARD CIRCUIT DIAGRAM & CIRCUIT BOARD.....	II-30
PKB EXP PEDAL KEYBOARD, EXPRESSION CIRCUIT DIAGRAM.....	II-30
PKB PEDAL KEYBOARD CIRCUIT BOARD.....	II-30
EXP EXPRESSION CIRCUIT BOARD.....	II-32

■ PART III (REPLACEMENT PARTS LIST)

REPLACEMENT PARTS LIST (P.C.B. and Wiring Parts).....	III-1
REPLACEMENT PARTS LIST (Cabinet and Chassis Parts).....	III-7
EXPLODED VIEWS OF CABINET.....	III-9
EXPLODED VIEWS OF STAND AND BENCH.....	III-11
PACKING.....	III-14


SAFETY PRECAUTION (This "safety precaution" is applied only in U.S.A.)

• Safety Precaution

1. Before servicing, unplug the power cord to prevent an electric shock.
2. When replacing parts, use only manufacturer's recommended components for safety.
3. Check the condition of the power cord. Replace if wear or damage is evident.
4. After servicing, be sure to restore the lead dress, insulation barriers, insulation papers, shields, etc.
5. Before returning the serviced equipment to the customer, be sure to make the following insulation resistance test to prevent the customer from being exposed to a shock hazard.

• Insulation Resistance Test

1. Unplug the power cord and short the two prongs of the plug with a jumper wire.
2. Turn on the power switch.
3. Measure the resistance value with ohmmeter between the jumpered AC plug and each exposed metal cabinet part, such as screw heads, connectors, control shafts, handle brackets, etc..
Measurements should range from 4MΩ to infinity to all exposed parts.



Resistance = 4 MΩ to ∞


HOW TO ASSEMBLE THE ORGAN

■ Screw kit

- Bolt ① () 4 pcs.
- Bolt ② () 4 pcs.


- Bolt ③ () 4 pcs.
- Cord clammer 3 pcs.

- 1** Use for black bolts ① and secure each side plank to the speaker box, then use for metal bolts ② to mount it on to the pedal as shown in the figure.




[Fig. 1]

- 2** Attach the rear board as shown.




[Fig. 2]

- 3** Place the upper organ part on the lower stand part, making sure to fit the metal pieces together.




[Fig. 3]

- 4** Using four bolts ①, secure the upper organ part to the lower stand part as shown in the figure.



[Fig. 4]



- 5** Connect the power cord, speaker cord and pedal cord as shown.



[Fig. 5]

- 6** Open the keyboard cover, and set it as shown so it can be used as a music rack.

EX-25L is not require this procedure.




[Fig. 6]


INSTALLATION OF SY-FD3 (OPTION)

Make sure that the Technics organ is turned off. Remove the screw from under the right side of the keyboard. The cover can now be removed from the Digital Disk Recorder compartment.

3. Insert the Digital Disk Recorder into the compartment opening and push it in firmly as far as it will go. Secure the Digital Disk Recorder with the screw that you removed in step 2.



[Fig. 7]



[Fig. 8]

15 ENDING

When this button is pressed, an ending rhythm pattern will be played and then the rhythm will stop.

16 ONE TOUCH PLAY

With this special feature, you select a rhythm and appropriate voice and effects are automatically set.

17 PLAY MODE

Select the type of accompaniment—either normal or automatic—or choose the accompaniment you programmed beforehand in the **PROGRAM CHORD COMPUTER**.

18 Auto Play Chord

This feature is selected when the **FINGERED** button in the **PLAY MODE** is turned on. When a single key on the lower keyboard is pressed, a full chord and a bass note sound. Play major, minor, seventh or minor seventh chords and the bass note just by pressing one key.

19 RECORD

This button is used to store the contents of the organ's various memories, including the **PROGRAM CHORD COMPUTER**, **PLAY SEQUENCER** or to store your performance with the optional Digital Disk Recorder. It is also used when setting the functions of the programmable switches.

20 PROGRAM CHORD COMPUTER

Use this feature to store the chord accompaniment of an entire song in the organ, then have it played back automatically while you play the melody. With the keys at the right end of your lower keyboard, store whole, half-or quarter-measure chords, specify repeat play, and more.

21 Programmable function switch

The foot switch can be programmed to conveniently turn on and off other functions, for example the rhythm start/stop or **TECHNI-CHORD**.

22 TECHNI-CHORD harmony styles

There are four harmony styles available for you to select from and store in the **CLOSE/PROGRAM** button of the **TECHNI-CHORD**.

23 TREMOLO speed adjustment

The **SLOW** and **FAST** buttons are also used to adjust the tremolo slow and fast speeds as desired.

24 Tuning

The sliding **TEMPO** control can also be used to adjust the pitch of the entire organ for ensemble play with other instruments.

25 Internal memory

The internal memory allows you to record your entire performance in the **PLAY SEQUENCER** or just the registrations and other stored functions for five complete tunes in the **FULLBAND SETTING COMPUTER**.

26 PLAY SEQUENCER

Use this memory to separately play and store the parts—bass, upper keyboard, lower keyboard and solo voices—of an entire tune. Then have the whole ensemble performance played back automatically.

27 FULLBAND SETTING COMPUTER

The voices, effects, chord and rhythms for up to five songs can be stored for easy recall.


28 Optional Digital Disk Recorder

If the Digital Disk Recorder is installed, you can have virtual unlimited storage and playback of your organ performances. Several tunes or one very long tune can be stored on each digital memory disk.

DIFFERENCE BETWEEN SX-EX25L AND SX-EX25


• SX-EX25L: The music rack is as shown below.

• SX-EX25: The keyboard cover is attached.



CONNECTION TERMINALS

(On the rear of the organ)



■ **LINE OUT** (output level 300 mV, 600Ω)


Use these outputs to connect the audio output of the organ to other audio equipment, such as a tape deck, VCR, audio mixer, tone cabinets, or additional amplifier/speaker systems.

■ **AUX IN** (input level 500mV, 20kΩ)


Use these inputs to connect the audio outputs of other audio equipment, such as a tape deck, VCR, tuner, or an audio mixer, for playback through the organ.

■ PHONES

(Use headphones with 16 ohm impedance.)
For silent practice headphones may be used.
When plugged in, the organ's speaker system
is automatically switched off, and the entire
organ is heard only through the headphones.




KEYBOARD RANGES




* An 8-feet compass is used for each keyboard.


ADJUSTMENT PROCEDURE

ADJUSTMENT	MEASURING CONDITIONS	EQUIPMENT	ADJUSTMENT P.C.B.	ADJ. POINT	CONNECT METER TO	METER READING
BBD Bias	Any position	Oscilloscope and Oscillator	MAIN P.C.B.	VR1	Check point ④⑧	Shown below
1. Connect the oscilloscope to check point ④⑧ of MAIN P.C.B. 2. Input 1 KHz sine-wave to IC50 ③ pin by oscillator through capacitor of less than 50V 1μF. Then adjust the output level of the oscillator until the sine wave on the oscilloscope is clipped. 3. Adjust VR1 so that the output waveforms on the oscilloscope are evenly clipped at top and bottom.						

PARTS LOCATION



[Photo-1]




[Photo-2]

DISASSEMBLY INSTRUCTIONS

1 Removing the Keyboard Cover (Fig. 9)

CAUTION: SX-EX25L is not require this procedure.


- ① Remove the keyboard cover holding screws. (A 4 pcs.)
- ② Lift the keyboard cover up. (As shown by the arrow.)



[Fig. 9]

2 Removing the upper rear board (Fig. 10)


- ① Remove the Keyboard Cover. (See Step 1)
- ② Remove the upper rear board holding screws. (E 12 pcs.) * (SX-EX25L: E 13 pcs.)



[Fig. 10]

3 Opening the Control Panel (Fig. 11)


- ① Remove the keyboard cover. (See step 1.)
- ② Remove the upper rear board. (See step 2.)
- ③ Remove the screws located on the bottom of the cabinet. (C 9 pcs.)
- ④ Lift the control panel up. (AS shown by the arrow.)



[Fig. 11]

4 Removing the Keyboard (Fig. 12)


- ① Remove the keyboard cover and upper rear board. (See step 1 and 2)
- ② Opening the control panel. (See step 3)
- ③ Remove the upper keyboard holding screws. (D 9 pcs.)
- ④ Remove the lower keyboard holding screws. (E 4 pcs.)



[Fig. 12]

5 Removing the Printed Circuit Board (Fig. 13)


- ① Remove the keyboard cover and upper rear board. (See step 1 and 2)
- ② Opening the control panel. (See step 3)
- ③ **MAIN** P.C.B.
 - Remove the screws located on the rear accessory panel. (Ⓢ 4 pcs.)
 - Remove the claws which inserted to the MAIN P.C.B. (Ⓢ 6 pcs.)
- ④ **AS** P.C.B. Ass'y
 - Remove the screws located on the rear accessory panel. (Ⓢ 4 pcs. & Ⓢ 2 pcs.)
 - Remove the claws which inserted to the **AS** P.C.B. Ass'y. (Ⓢ 3 pcs.)



[Fig. 13]

6 Removing the Pedal Keyboard (Fig. 14)


- ① Remove the pedal keyboard holding screws. (Ⓢ 7 pcs.)



[Fig. 14]

7 Removing the Speaker (Fig. 15)

- ① Remove the rear board holding screws. (Ⓢ 11 pcs.)
- ② Remove the speaker mounting nuts. (Ⓢ 4 pcs.)



[Fig. 15]

PRECAUTIONS BEFORE SERVICING

■ Precautions for measuring of the output waveforms.

1. Please set the initial mode (factory-preset mode) before measurement.
2. After initial mode, set the measurement conditions as each check points.
3. The waveform was measured by "National Digital Storage Oscilloscope VP-5730A". Therefore the waveforms of musical tone signals shown may somewhat change due to variation of timing of triggering.
4. Since the 1/10 of the test probe is used, the indicated voltage value on bottom part of the each waveform photo is 1/10 of the actual value. (e.g. 0.2V/cm should be 2.0V/cm)

■ Important safety notice:

Components identified by $\triangle$ mark have special characteristics important for safety.
When replacing any of these components, use only manufacturer's specified parts.

■ Symbolic Marks

The symbolic marks for resistors and capacitors which are used in this circuits are classified as following TABLE-1 and TABLE-2.

1. RESISTORS

- Resistors without symbolic mark are FIXED CARBON FILM RESISTORS (ERD-type).
- All resistors are 1/4WATT, $\pm 5\%$ TOLERANCE unless otherwise designated in the schematic diagrams.

(TABLE-1)

SYMBOL	SPECIFICATION	SYMBOL	SPECIFICATION
Ⓕ	Fixed Carbon Film Resistors "FLAME-PROOF" (ERD—F—type)	Ⓕ	Fixed Metal Film Resistors "FLAME-PROOF" (ERX—type)
Ⓕ	Fixed Wire Wound Resistors "FLAME-PROOF" (ERF—type)	Ⓕ	Fuse Type Fixed Metal Oxide Film Resistors "FLAME-PROOF" (ERQ—type)
Ⓕ	Fixed Metal Oxide Film Resistors "FLAME-PROOF" (ERG—type)	Ⓕ	Fuse Type Fixed Carbon Film Resistors "FLAME-PROOF" (ERD2FC—type)
	Fixed Metal Film Resistors (Precision and High Stability) (ERO—type)		

2. CAPACITORS

- Capacitors without symbolic mark are POLYESTER CAPACITORS. (ECQM-type, ECQG-type, $\pm 10\%$ Tolerance)
- Polarized capacitors without symbolic mark are Aluminum Electrolytic Capacitors.
(ECEA—type, $\pm 20\%$ Tolernace)

(TABLE-2)

SYMBOL	SPECIFICATION	TYPE
Ⓐ	Non-Polarised Electrolytic Capacitors	ECEA—N—type
Ⓐ	Non-Polarised Electrolytic (for Network System)	ECEA—Y—type
Ⓐ	Aluminum Electrolytic Capacitors (Miniature type)	ECEA—K—type ECEA—X—type
Ⓐ	Aluminum Electrolytic Capacitors (Low leakage current type)	ECEA—M—type
Ⓐ	Aluminum Electrolytic Capacitors (Low impedance type)	ECEA—Z—type
Ⓐ	Metalized Plastic Film Capacitors (TF Series)	ECQV—type
	Polyester Film Capacitors	ECQB—type
○	Temperature Compensating Ceramic Capacitors	ECC—type
	High-Dielectric Constant Ceramic Capacitors	ECK—type
	High-Dielectric Constant Ceramic Capacitors	ECRR—type
	Ceramic Capacitors (Cylinder type)	ECBA—type
	Metalized Polyester Film Capacitors for Across the Line	ECQ—EW—type
	Aluminum Electrolytic Capacitors for smooting Circuit	ECES—type

SYMPTOMS WHICH APPEAR TO BE SIGNS OF TROUBLE

The following changes in performance may occur in the Technics organ but do not indicate trouble:

Phenomenon	Remedy
The buttons, keyboards, etc. malfunction.	■ Press the FSC button first to turn it on and then press the INITIAL key on the lower keyboard. ● If the buttons, keyboards, etc. do not return to normal, turn the POWER switch off once, then turn on again.
Different voices are heard in the lower and upper half keys on the upper keyboard.	The lower portion of the upper keyboard is used to monitor the lower keyboard voices when the lower keyboard is required for programming functions.
A rhythm does not start or no rhythm sounds.	● No rhythm sounds if the DRUMS VOLUME buttons are turned off. ● The rhythm does not start when you turn on a PLAY SEQUENCER button in which a tune with no rhythm is stored.
The glide control does not operate properly.	Any functional on and off operation other than the glide is storable in the foot switch.
The TREMOLO speed is improper.	The TREMOLO speed is adjustable. Adjust to your favorite speed.
The contents of the PROGRAM CHORD COMPUTER , FULLBAND SETTING COMPUTER etc. cannot be stored.	After pressing the RECORD button, press the necessary buttons within 5 seconds. The RECORD button turns off after a lapse of 5 seconds, making storage operation impossible. Press the RECORD button again.
When storing voices and effects in the VOICE SETTING COMPUTER , voices other than those desired are stored.	● To store voices and effects, press the 1~4 buttons of the VOICE SETTING COMPUTER while the SET button is held down. ● To select your favorite registration from the 32 factory-preset voice combinations, press the RECORD button and depress one of the number buttons of the VOICE SETTING COMPUTER within 5 seconds. Then press RHYTHM button(s). Finally, press the selected number button again.
Storage is not possible with the PROGRAM CHORD COMPUTER .	● Check that the PCC indicator is slowly flashing. Pressing the FINGERED button turns off the RECORD button, making storage operation impossible. ● Do not release the left hand (chord designation) before pressing the measure keys (,  and ).
The stored registration cannot be used when performance is started with the PLAY SEQUENCER button turned on.	To use the stored registration, turn on the FSC button and then press the 1 key on the lower keyboard.
The stored introduction is not reproduced during automatic performance.	● Set the beginning of a song, such as an introduction, before turning on the RECORD button. ● To add an introduction after the RECORD indicator and PLAY SEQUENCER indicator flash, set it after turning on the FSC button. Then turn off the FSC button.
No storage is possible even when the RECORD indicator and PLAY SEQUENCER indicator are slowly flashing.	● No storage is possible when the FSC button is turned on. Turn it off before playing. ● If another PLAY SEQUENCER indicator is lit, press the START/STOP button for automatic performance of the stored part. Another part can then be stored.

Phenomenon	Remedy
The quick rhythm tempo is delayed when the PLAY SEQUENCER is used.	This occurs when too many notes are played at one time. Slow down the tempo (to about ♩=180) or reduce the number of notes played at a time.
Different voices and effects are stored in the FULLBAND SETTING COMPUTER (FSC) .	If the VOICE SETTING COMPUTER function is selected, the stored contents in this button are stored into the FSC . When the voices and effects selected by the VOICE SETTING COMPUTER are changed, store them in the VOICE SETTING COMPUTER again before storage in the FSC .
The cabinet becomes heated to some degree.	The Technics organ has a built-in power source that heats the cabinet to some degree. This is not an indication of trouble.

ERROR DISPLAY

When using the Digital Disk Recorder or the organ's internal memory and an error (Error) is indicated on the **MUSICAL DISPLAY**, the number following indicates the type of error.

Error No.	Problem	Cause
Nothing appears on the display.	The memory disk format is different (when recording).	The disk used is not a NORMAL mode or PRO mode disk. Initialize the disk.
1	The mode change function of the internal memory and the Digital Disk Recorder does not work.	•When Digital Disk Recorder is installed, the operation to change the internal memory mode (FSC/PS) is performed. •No memory disk is inserted. •The memory disk is write-protected.
2	Data transmission error when loading from or saving on a memory disk.	An error occurred during data transmission with the memory disk. Perform the loading or saving procedure once again.
3	Recording in or playing back from the organ's internal memory is unsuccessful.	The memory track number specified is not correct. Specify 1~5.
5	Loading or saving on a memory disk is unsuccessful.	•The memory track number is not correct. In the PRO mode, specify 1; in the NORMAL mode, specify 1~20. •No memory disk is inserted. •The memory disk is write-protected (when recording).

MIDI IMPLEMENTATION CHART

Technics Organ
[SX-EX15L/SX-EX25L/SX-EX35]

(Transmitted)

Function...		upper	lower	bass	solo	Remarks
Basic Channel	Initialized Default Changed	1 1~16 1~16	2 1~16 1~16	3 1~16 1~16	4 1~16 1~16	memorized
Mode	Default Messages Altered	3 × _____	3 × _____	3 × _____	3 × _____	
Note Number	True voice	17~127 _____	5~120 _____	0~84 _____	17~127 _____	Including the use of Octave Shift
Velocity	Note ON Note OFF	× × (9nH:V=0)	× × (9nH:V=0)	× × (9nH:V=0)	× × (9nH:V=0)	
After Touch	Key's Ch's	× ×	× ×	× ×	× ×	
Pitch Bender		×	×	×	×	
Control Change	64	*○ ×	× (EX15) *○ × (EX25/EX35)	×	×	sustain
	94	*○ ×	*○ ×	×	×	celeste
Prog Change	True #	*○ × 0~ 8 (EX15) 0~15 (EX25/EX35)	*○ × 0~ 8 (EX15) 0~11 (EX25/EX35)	*○ × 0~2 (EX15) 0~7 (EX25/EX35)	*○ × 0~7 _____	
System Exclusive		×				
System Common	Song Pos Song Sel Tune	× ○ (EX15) *○ × (EX25/EX35) ×				
System Real Time	Clock Commands	○ *○ ×				
Aux	Local ON/OFF All Notes OFF	× ○	× ○	× ○	× ○	
Messages	Active Sense Reset	○ ×				
Notes						

Mode 1: OMNI ON, POLY Mode 2: OMNI ON, MONO ○ : Yes
Mode 3: OMNI OFF, POLY Mode 4: OMNI OFF, MONO × : No

Technics Organ
[SX-EX15L/SX-EX25L/SX-EX35]

(Recognized)


Function...		upper	lower	bass	solo	Remarks
Basic Channel	Initialized Default Changed	1 1~16 1~16	2 1~16 1~16	3 1~16 1~16	4 1~16 1~16	memorized
Mode	Default Messages Altered	3 × —	3 × —	3 × —	3 × —	OMNI OFF POLY Mode
Note Number	True voice	0 ~127 **36~107 (EX15) 36~119	0~127 **36~107 (EX15) 36~119	0~127 **36~107	0~127 48~107	Changes depending on the position of the Transpose slide control or Octave Shift.
Velocity	Note ON Note OFF	× × (9nH:V=0)	× × (9nH:V=0)	× × (9nH:V=0)	× × (9nH:V=0)	
After Touch	Key's Ch's	× ×	× ×	× ×	× ×	
Pitch Bender		×	×	×	×	
Control Change	64	*○ ×	× (EX15) *○ × (EX25/EX35)	×	×	sustain
	94	*○ ×	*○ ×	×	×	celeste
Prog Change	True #	*○ × 0~8 (EX15) 0~3 (EX25) 0~6 (EX35)	*○ × (EX15) × (EX25/EX35) 0~8 (EX15)	*○ × 0~2 (EX15) 0~7 (EX25/EX35)	*○ × 0~7	
System Exclusive		×				
System Common	Song Pos Song Sel Tune	× × (EX15) ○* × (EX25/EX35) ×				
System Real Time	Clock Commands	○ *○ ×				
Aux	Local ON/OFF All Notes OFF	× ○	× ○	× ○	× ○	(123~127)
Messages	Active Sense Reset	○ ×				
Notes *○ ×..... Whether or not the data for each of these items is received can be set. **Changes depending on the selected voice.						


Mode 1: OMNI ON, POLY Mode 2: OMNI ON, MONO ○ : Yes
Mode 3: OMNI OFF, POLY Mode 4: OMNI OFF, MONO × : No

• This product adheres to MIDI specifications as published by the Japan MIDI Association.

F








MAIN MAIN CIRCUIT BOARD

NOTE: Resistor marked JR on the printed circuit board are the impedance "ZERO ohm" resistors as the same as jumper wires.

* P.C.B. Comparison chart by area.


Area	P.C.B. No.	C4, 5	L3
M	SXPG144641	x	
MC, EZ, XL	SXPG144651	x	
Others	SXPG144621	o	

1, 2




• Power SW.....OFF → ON

1, 2




• Power SW.....ON → OFF

1, 3




• Power SW.....OFF → ON


1, 3



• Power SW.....ON → OFF




4




• MIDI Signal Out
• Upper C4 key ON


7 SCK, 5 TXD




7 SCK, 6 RXD





7 SCK, 8 EOB



9 Main Vol., EXP Control 10 Rhythm Vol. Control 11, 12




• Exp Pedal Max.
• Main Vol. Step 1~4
• Upper key ON



• Tremolo Fast 6.5Hz
• Tremolo Slow 0.5Hz
• Celeste 0.5Hz

14 16 MHz




II - 6

II - 7


II - 8

21, 22




- L. Tab. Flute 8'
- L. Poly Vol. Max.
- Lower key C3

25 Accomp




- Rhythm: March • Tempo: ♩ = 120
- Play Mode: Fingered • Lower key: C
- Accomp: 1/2 ON • Accomp Vol.: Max.

28



- U. Tab. Flute 8'
- U. Poly Vol. Max.
- Upper key C4

32




- U. Tab. Flute 8'
- U. Poly Vol. Max.
- Upper key: C4 • Effect: OFF

35 Main Vol., EXP Control

- Main Volume
- Step 1 -3.8V
- Step 2 -3.0V
- Step 3 -2.2V
- Step 4 -1.4V


- EXP Pedal Max.
- Main Vol. Step 1~4
- Upper key ON

23 Solo




- U. Solo Flute
- Upper key C4
- Solo Vol. Max.

26 Lower Poly



- L. Tab. Flute 8'
- L. Poly Vol. Max.
- Lower key C3

29




- U. Tab. Flute 8'
- U. Poly Vol. Max.
- Upper key C4
- U. Tab. Effect.....Celeste

33 Drums Vol. Control


- Drums Volume
- Step 1 -10.8V
- Step 2 -7.0V
- Step 3 -3.5V
- Step 4 -0V

36




- U. Tab. Flute 8'
- U. Poly Vol. Main Vol.: Max.
- EXP Pedal: Max. • Upper key: C4

24 Upper Poly




- U. Tab. Flute 8'
- U. Poly Vol. Max.
- Upper key C4

27 Bass




- Bass 16'
- Bass key C2
- Bass Vol. Max.

30 EFNG




- Conductor U. poly
- U. Tab. Effect.....Celeste
- Upper key ON → OFF
- OFF → ON

34 Drum Percussion



- Rhythm March
- Tempo.....♩ = 120
- Drums Vol. Max.


37



38


- Effect
- Celeste..... 0V
- Tremolo..... +15V

39 Celeste




- Effect Celeste

39 Tremolo Slow




- Effect Tremolo Slow

39 Tremolo Fast




- Effect Tremolo Fast

40 Celeste




- Effect Celeste

40 Tremolo Slow




- Effect Tremolo Slow

40 Tremolo Fast




- Effect Tremolo Fast

41 Celeste




- Effect Celeste

41 Tremolo Slow




- Effect Tremolo Slow

41 Tremolo Fast




- Effect Tremolo Fast

42, 43, 44




- Effect Celeste

45, 46, 47



- U. Tab. Flute 8'
- U. Poly Vol.....Max.
- Upper key C4
- U. Tab. Effect.....Celeste

48




- U. Tab. Flute 8'
- U. Poly Vol.....Max.
- Upper key C4
- U. Tab. Effect.....Celeste

MAIN

FDCN


MAIN, FD CONNECTOR CIRCUIT DIAGRAM


MAIN MAIN CIRCUIT



II-11

II-12






SXPG135211A

NOTES:

- IC'S
 - IC1: MN15524PGY
 - IC2~4: SVIGM74LS07
- TRANSISTORS
 - Q1~4: 2SA830B
 - Q5~Q6: 2SC1047C
 - Q7: 2SA1015-GR
- DIODES
 - D3, 6~24, 27~45, MA165TA5
 - 49~67, 70~87, 173, 175:

- LED'S

- D89~99, SVDGSEL4117R
102~107,
109~127,
134~148,
151~166, 168:
D100, 101, SVDGSEL4417G
131~133, 167,
174:



NOTES:

- IC'S
- IC1: MN15524PGY
- IC2~4: SVIGM74LS07
- TRANSISTORS
- Q1~4: 2SA830B
- Q5~Q6: 2SC1047C
- Q7: 2SA1015-GR
- DIODES
- D3, 6~24, 27~45, MA165TA5
- 49~67, 70~87, 173, 175:


• LED'S

- D89~99, SVDGSEL4117R
- 102~107,
- 109~127,
- 134~148,
- 151~166, 168:
- D100, 101, SVDGSEL4417G
- 131~133, 167,
- 174:

CPL CP CONTROL PANEL LEFT, RIGHT CIRCUIT BOARD

CPL CONTROL PANEL LEFT

SXPG144911




CPL NOTES:

- IC'S
IC1, 2: SVIGM74LS174
IC3: SVIGM74LS138
IC4: SVIGUPD7225
- TRANSISTORS
Q1: 2SA1015-GR
Q2, 3: 2SC2320LFG
- DIODES
D1~12: MA165TA5
D13~24: SVDGSEL4117R

CP CONTROL PANEL RIGHT

SXPG135331



CP NOTES:

- IC'S
IC1: SVIGM74LS138
IC3: SVIGM74LS174
- TRANSISTOR
Q1: 2SA1015-GR
- DIODES
D13~16: MA165TA5
D19, 23~25: SVDGSEL4417G

A

B


C

D

E


F

CPL CONTROL PANEL LEFT CIRCUIT



II-23

CP CONTROL PANEL RIGHT CIRCUIT




II-24

CPL NOTES:

- IC'S
- IC1, 2: SVIGM74LS174
- IC3: SVIGM74LS138
- IC4: SVIGUPD7225
- TRANSISTORS
- Q1: 2SA1015-GR
- Q2, 3: 2SC2320LFG
- DIODES
- D1~12: MA165TA5
- D13~24: SVDGSEL4117R

CP NOTES:

- IC'S
- IC1: SVIGM74LS138
- IC3: SVIGM74LS174
- TRANSISTOR
- Q1: 2SA1015-GR
- DIODES
- D13~16: MA165TA5
- D19, 23~25: SVDGSEL4417G



NOTES:

• IC'S
IC1: SVIGM5F7815
IC2: SVIGM5F7915
IC3: SVIGM5291P

• TRANSISTORS
Q1~3, 5, 2SC2320LFG
6, 11:
Q4: 2SB953A
Q7: 2SA1123R
Q8: 2SC1815GR
Q9: 2SD1277A
Q10: 2SB951A

• DIODES
D1, 2: SVDGERA1502Y
D3~6: SVDGS3V20-15
D7~9: MA165TA5
D10: SVDGRK14
D11: MA4062
D12: MA2062LF

* P.C.B. Comparison chart by area.

Area	P.C.B. No.	C3	F1	F2	F3	F4	AC Inlet Cover
M. MC	SXPG135211B	○	4A, 125V		x	x	SJS9231A
N	SXPG135212B	x	4A, 125V		x	x	
EN	SXPG135271B	x			x	4A, 250V	
EZ	SXPG1352131B	○	x	1.6A, 250V			SJS9334A
XL, XR	SXPG135291B	○	3.15A, 250V	1.6A, 250V	1.6A, 250V	4A, 250V	SJS9231A
Others	SXPG135281B	x					

■ Products for (M) and (MC) areas.

SXPG1352111B

■ Products for (N) area.


SXPG1352121B

■ Products for (EN) area.

SXPG135271B

■ Products for (EZ) area.

SXPG1352131B



NOTES:

• FUSES


M MC F1, F2: XBA1C40NU100

N F1, 2: XBA1C40NS5

* P.C.B. Comparison chart by area.


Area	P.C.B. No.	C3
M, MC	SXPG1352111B	○
N	SXPG1352121B	x

1 RST1





• Power SW. ON → OFF

2



• Power SW. ON → OFF

3



NOTES:

• FUSES


F2: XBA2C16TBO

F4: XBA2C40TBO


* P.C.B. Comparison chart by area.

Area	P.C.B. No.	C3
EN	SXPG135271B	x
EZ	SXPG1352131B	○

4, 5




6 IN



• Upper Tab. Flute 8'
 • U. Poly Volume Step 4
 • Main Vol. Exp Max
 • Upper Key C4

7 OUT




• Upper Tab. Flute 8'
 • U. Poly Volume Step 4
 • Main Vol. Exp Max
 • Upper Key C4

11B
21B

■ Products for (EN) area. **SXPG135271B**
■ Products for (EZ) area. **SXPG1352131B**


■ Products for (XL) and (XR) areas. **SXPG135291B**
■ Products for Asia and European areas except (EN) and (EZ). **SXPG135281B**



NOTES:
• FUSES
F2: XBA2C16TBO
F4: XBA2C40TBO

* P.C.B. Comparison chart by area.

Area	P.C.B. No.	C3
EN	SXPG135271B	x
EZ	SXPG1352131B	○





NOTES:
• FUSES
F1: XBA2C31TBO
F2, 3: XBA216TBO
F4: XBA2C40TBO





* P.C.B. Comparison chart by area.

Area	P.C.B. No.	AC Inlet Cover	C3
XL, XR	SXPG135291B	SJS9334A	○
Others	SXPG135281B	SJS9231A	x

HP HEADPHONES CIRCUIT BOARD




SXPG135211C



PKB

EXP

PEDAL KEYBOARD & EXP CIRCUIT DIAGRAM




- NOTES:
- IC
IC1: SVIGM74LS138
 - DIODES
D1~44: MA162A

A

B

C


PEDAL KEYBOARD CIRCUIT




MAIN
JK8

- NOTES:
- TRANSISTOR
Q1, 2, 4: 2SA1015-GR
Q5~17: 2SC2320LFG


EXPRESSION CIRCUIT




EXP P.C.B. SXPG103211



SXPG145111



SXPG145311



REPLACEMENT PARTS LIST.....P.C.B. and Wiring Parts

Notes:

1. Printed circuit board assembly with mark (NLA) is no longer available after production discontinuation of the complete set.
2. The MAIN P.C.B. part number is service standard parts and may differ from production parts. (Except [M] area)
3. The "S" mark is service standard parts and may differ from production parts.

4. Important safety notice

Components identified by Δ mark have special characteristics important for safety. When replacing any of these components, use only manufacturer's specified parts.

5. $\bigcirc$ mark are new parts.

6. For part No. with area mark, check the area when placing an order.

PRINTED CIRCUIT BOARD

	NLA	Area	Part No.	Description	Per/Set
$\bigcirc$	NLA	M	SXPG144641	MAIN	1
$\bigcirc$	NLA		SXPG144651	MAIN others	1
$\bigcirc$	NLA		SXPG141931	FDCN	1
$\bigcirc$	NLA		SXPG135411	DP	1
$\bigcirc$	NLA		SXPG1352111A	CPSL	1
$\bigcirc$	NLA		SXPG144911	CPL	1
$\bigcirc$	NLA		SXPG135331	CP	1
$\bigcirc$	NLA	M MC	SXPG1352111B	AS	1
$\bigcirc$	NLA	EZ	SXPG1352131B	AS	1
$\bigcirc$	NLA	XL XR	SXPG135291B	AS	1
$\bigcirc$	NLA	EN	SXPG135271B	AS	1
$\bigcirc$	NLA		SXPG135281B	AS others	1
$\bigcirc$	NLA		SXPG135211C	HP	1
$\bigcirc$	NLA		SXPG145311	MKB	2
$\bigcirc$	NLA		SXPG145111	PKB	1
$\bigcirc$	NLA		SXPG103211	EXP	1

MAIN MAIN CIRCUIT

	Ref. No.	Part No.	Description	Per/Set
INTEGRATED CIRCUITS				
$\bigcirc$	IC1	SVIG7810HCW	1 chip 8 bit Microcomputer	1
	IC2	SVIGM6050211	Gate Array	1
	IC3	SVIGAEX25AX2	1M bit EP ROM	1
	IC4	SVIGD446415L	64K bit SRAM	1
	IC6	SVIGM74LS05	Hex Inverters (O.C.)	1
	IC7	SVIGTLP513	Photo Coupler	1
	IC10, 11, 21~23, 34, 36, 39, 42, 44, 45, 53, 70	SVIGM5218L	Operational Amplifier	13
	IC12, 14	MN6635	Tone Generator LSI	2
$\bigcirc$	IC13	SVIGU3C04616	4M bit Mask ROM	1
	IC15, 16	SVIGBA9221	12 bit D-A Converter	2
	IC17, 18	SVIGM5238L	Operational Amplifier	2
	IC19, 20	SVIGTC4051BP	8-channel Multiplexer	2
	IC24~31	MN74HC4066	Quad Bilateral Switches	8
	IC41	SVIGM5241L	Dual VCA	1
	IC46	SVIGUPD4066B	Bilateral Switch	1
	IC47~49	SVIGMSM4011	2-input NAND Gate	3
	IC50~52	MN3006	BBD (128 stages)	3
	IC65	SVIGLM1894N	Dynamic Noise Reduction	1
TRANSISTORS				
S	Q1~3	2SC2320LFG	2SC1310FG (SUB. Part)	3
	Q14, 15 M	2SB941	[M] area only	2
	Q5, 10, 11, 13	2SJ105GR	FET	4
S	Q8, 9	2SA1015-GR	2SA933STRS (SUB. Part)	2
DIODES				
	D1~19	MA165TA5		19

	Ref. No.	Part No.	Description	Per/Set
OSCILLATORS				
	X1	SVQG49S1500T	15 MHz, Quartz Oscillator	1
	X2	EF0FC4004A3	4 MHz, Ceramic Oscillator	1
	X3	SVQG49S1600T	16 MHz, Quartz Oscillator	1
COMPONENT COMBINATIONS				
	Z2	EXBP88472JM	4.7K Ω $\times$ 8	1
	Z3, 4	EXKS14Z2073	1K Ω /2K Ω , Ladder Network	2
COILS				
	L3~5, 11~13	SLQG15W34DPQ	Coil, [M][MC][EZ][XL] areas only	6
JACKS				
	JK1~3	SJSG1370A	MIDI (IN, OUT, THRU)	3
	JK5, 7	SJJG400A	LINE OUT, AUX IN	2
	JK8	SJSG1390A	PEDAL	1
SEMI-FIXED RESISTOR				
	VR1	EVSG0E1B223A	22K Ω B, BBD Bias Adj.	1
RESISTORS				
	R1, 2	ERDS2TJ472	4.7K Ω	2
	R3	ERDS2TJ471	470 Ω	1
	R4	ERDS2TJ332	3.3K Ω	1
	R5	ERDS2TJ681	680 Ω	1
	R6	ERDS2TJ330	33 Ω	1
	R7	ERDS2TJ102	1K Ω	1
	R8	ERDS2TJ330	33 Ω	1
	R9	ERDS2TJ333	33K Ω	1
	R10	ERDS2TJ472	4.7K Ω	1
	R11	ERDS2TJ473	47K Ω	1
	R14	ERDS2TJ472	4.7K Ω	1
	R15	ERDS2TJ101	100 Ω	1
	R16	ERDS2TJ184	180K Ω	1
	R17	ERDS2TJ101	100 Ω	1
	R18 Δ	ERD2FCJ4R7	4.7 Ω , 1/4W, Fuse Type	1
	R19	ERDS2TJ223	22K Ω	1
	R21	ERDS2TJ223	22K Ω	1
	R23, 24	ERDS2TJ472	4.7K Ω	2
	R25	ERDS2TJ103	10K Ω	1
	R27	ERDS2TJ221	220 Ω	1
	R28~30	ERDS2TJ101	100 Ω	3
	R31	ERDS2TJ334	330K Ω	1
	R32	ERDS2TJ103	10K Ω	1
	R33	ERDS2TJ101	100 Ω	1
	R34	ERDS2TJ334	330K Ω	1
	R35	ERDS2TJ103	10K Ω	1
	R39	ERDS2TJ105	1M Ω	1
	R40	ERDS2TJ472	4.7K Ω	1
	R41	ERDS2TJ333	33K Ω	1
	R42	ERDS2TJ222	2.2K Ω	1
	R43	ERDS2TJ103	10K Ω	1
	R44	ERDS2TJ184	180K Ω	1

Ref. No.	Part No.	Description	Per/Set	Ref. No.	Part No.	Description	Per/Set
R45	ERDS2TJ474	470KΩ	1	R229	ERDS2TJ223	22KΩ	1
R46	ERDS2TJ124	120KΩ	1	R230	ERDS2TJ332	3.3KΩ	1
R47	ERDS2TJ184	180KΩ	1	R231	ERDS2TJ184	180KΩ	1
R48	ERDS2TJ124	120KΩ	1	R232	ERDS2TJ153	15KΩ	1
R50	ERDS2TJ471	470Ω	1	R233	ERDS2TJ103	10KΩ	1
R58	ERDS2TJ105	1MΩ	1	R234, 235	ERDS2TJ153	15KΩ	2
R59, 60	ERDS2TJ124	120KΩ	2	R236	ERDS2TJ223	22KΩ	1
R61, 62	ERDS2TJ471	470Ω	2	R237	ERDS2TJ153	15KΩ	1
R63	ERDS2TKF4700	470Ω, ±1%	1	R239, 240	ERDS2TJ153	15KΩ	2
R64, 65	ERDS2TJ471	470Ω	2	R241	ERDS2TJ223	22KΩ	1
R66	ERDS2TJ123	12KΩ	1	R242	ERDS2TJ184	180KΩ	1
R67	ERDS2TKF4700	470Ω, ±1%	1	R243, 244	ERDS2TJ332	3.3KΩ	2
R68, 69	ERDS2TJ473	47KΩ	2	R245, 246	ERDS2TJ184	180KΩ	2
R73	ERDS2TJ473	47KΩ	1	R247, 248	ERDS2TJ332	3.3KΩ	2
R77	ERDS2TJ473	47KΩ	1	R249	ERDS2TJ184	180KΩ	1
R81	ERDS2TJ473	47KΩ	1	R255	ERDS2TJ473	47KΩ	1
R85	ERDS2TJ473	47KΩ	1	R256	ERDS2TJ472	4.7KΩ	1
R89	ERDS2TJ473	47KΩ	1	R257	ERDS2TJ124	120KΩ	1
R93	ERDS2TJ473	47KΩ	1	R269	ERDS2TJ473	47KΩ	1
R97	ERDS2TJ473	47KΩ	1	R270	ERDS2TJ153	15KΩ	1
R101	ERDS2TJ473	47KΩ	1	R272	ERDS2TJ152	1.5KΩ	1
R102	ERDS2TJ683	68KΩ	1	R273	ERDS2TJ184	180KΩ	1
R103	ERDS2TJ224	220KΩ	1	R274	ERDS2TJ331	330Ω	1
R104	ERDS2TJ333	33KΩ	1	R275	ERDS2TJ681	680Ω	1
R109	ERDS2TJ473	47KΩ	1	R276	ERDS2TJ331	330Ω	1
R113	ERDS2TJ473	47KΩ	1	R277	ERDS2TJ471	470Ω	1
R117	ERDS2TJ473	47KΩ	1	R278	ERDS2TJ101	100Ω	1
R121	ERDS2TJ473	47KΩ	1	R279	ERDS2TJ333	33KΩ	1
R125	ERDS2TJ473	47KΩ	1	R280, 281	ERDS2TJ222	2.2KΩ	2
R129	ERDS2TJ473	47KΩ	1	R283, 284	ERDS2TJ153	15KΩ	2
R133	ERDS2TJ473	47KΩ	1	R285	ERDS2TJ682	6.8KΩ	1
R136	△ ERD2FCG220	22Ω, 1/4W, Fuse Type	1	R286	ERDS2TJ223	22KΩ	1
R137	ERDS2TJ473	47KΩ	1	R290	ERDS2TJ683	68KΩ	1
R138, 139	ERDS2TJ333	33KΩ	2	R291	ERDS2TJ471	470Ω	1
R140, 141	ERDS2TKF4700	470Ω, ±1%	2	R293	ERDS2TJ103	10KΩ	1
R142, 143	ERDS2TJ471	470Ω	2	R296	ERDS2TJ474	470KΩ	1
R148	ERDS2TJ223	22KΩ	1	R297	ERDS2TJ472	4.7KΩ	1
R149	ERDS2TJ103	10KΩ	1	R301	ERDS2TJ223	22KΩ	1
R150	ERDS2TJ223	22KΩ	1	R302	ERDS2TJ104	100KΩ	1
R151	ERDS2TJ103	10KΩ	1	R303	ERDS2TJ472	4.7KΩ	1
R152	ERDS2TJ223	22KΩ	1	R305	△ ERQ14AJ2R0P	2Ω, 1/4W, Fuse Type	1
R153	ERDS2TJ103	10KΩ	1	R306, 307	△ ERD2FCJ4R7	4.7Ω, 1/4W, Fuse Type	2
R155~158	ERDS2TJ223	22KΩ	4	R308	ERDS2TJ473	47KΩ	1
R160	ERDS2TJ473	47KΩ	1	R309	ERDS2TJ102	1KΩ	1
R169	ERDS2TJ472	4.7KΩ	1	R312	ERDS2TJ472	4.7KΩ	1
R170~172	ERDS2TJ473	47KΩ	3	R315	ERDS2TJ154	150KΩ	1
R177	ERDS2TJ472	4.7KΩ	1	R317	ERDS2TJ333	33KΩ	1
R178~180	ERDS2TJ473	47KΩ	3	R318	ERDS2TJ153	15KΩ	1
R181	ERDS2TJ472	4.7KΩ	1	R319	ERDS2TJ103	10KΩ	1
R182~184	ERDS2TJ473	47KΩ	3	R321	ERDS2TJ154	150KΩ	1
R190	ERDS2TJ105	1MΩ	1	R322	△ ERD2FCG220	22Ω, 1/4W, Fuse Type	1
R197	ERDS2TJ472	4.7KΩ	1	R323	ERDS2TJ154	150KΩ	1
R198	ERDS2TJ474	470KΩ	1	R324	ERDS2TJ153	15KΩ	1
R199	ERDS2TJ104	100KΩ	1	R325	ERDS2TJ333	33KΩ	1
R200	ERDS2TJ332	3.3KΩ	1	R326	ERDS2TJ154	150KΩ	1
R201	ERDS2TJ474	470KΩ	1	R327	ERDS2TJ103	10KΩ	1
R202	ERDS2TJ104	100KΩ	1	R328, 329	ERDS2TJ333	33KΩ	2
R203	ERDS2TJ222	2.2KΩ	1	R330	△ ERD2FCG220	22Ω, 1/4W, Fuse Type	1
R204	ERDS2TJ223	22KΩ	1	R331	ERDS2TJ154	150KΩ	1
R205, 206	ERDS2TJ103	10KΩ	2	R333	ERDS2TJ103	10KΩ	1
R215~220	ERDS2TJ474	470KΩ	6	R334	ERDS2TJ154	150KΩ	1
R221, 222	ERDS2TJ223	22KΩ	2	R339	ERDS2TJ331	330Ω	1
R223	ERDS2TJ473	47KΩ	1	R340	ERDS2TJ123	12KΩ	1
R224	ERDS2TJ184	180KΩ	1	R344	ERDS2TJ333	33KΩ	1
R225	ERDS2TJ332	3.3KΩ	1	R346, 347	△ ERX2ANJPR22S	0.22Ω, 2W, Flame-Proof	2
R226	ERDS2TJ153	15KΩ	1	R348	ERDS2TJ822	8.2KΩ	1
R227	ERDS2TJ103	10KΩ	1	R349	ERDS2TJ102	1KΩ	1
R228	ERDS2TJ153	15KΩ	1	R350	ERDS2TJ151	150Ω	1

Ref. No.	Part No.	Description	Per/Set
R353	ERDS2TJ474	470 KΩ	1
R355	ERDS2TJ473	47 KΩ	1
R358	ERDS2TJ472	4.7 KΩ	1
R365	ERDS2TJ472	4.7 KΩ	1
R382	ERDS2TJ153	15 KΩ	1
R401	ERDS2TJ472	4.7 KΩ	1
R402	ERDS2TJ105	1 MΩ	1
R403	ERDS2TJ472	4.7 KΩ	1
R404	ERDS2TJ105	1 MΩ	1
R407, 408	ERDS2TJ472	4.7 KΩ	2
R410	ERDS2TJ681	680Ω	1
R411	ERDS2TJ333	33 KΩ	1
R412	ERDS2TJ153	15 KΩ	1

CAPACITORS

C1	ECCR1H221J	220 pF	1
C2	ECKR1E473ZV	0.047 μF	1
C3	ECQG1H102KZ	0.001 μF	1
C4, 5	ECCR1H220J	22 pF, Except [M][MC][EZ][XL] areas	2
C6, 7	ECKR1E473ZV	0.047 μF	2
C8	ECEA0JU101	100 μF, 6.3 V	1
C9	ECEA0JU331	330 μF, 6.3 V	1
C10~12	ECKR1E473ZV	0.047 μF	3
C15	ECEA1HU010	1 μF, 50 V	1
C16	ECQM1H153KV	0.015 μF	1
C17	ECQV1H224JZ	0.22 μF	1
C19	ECQM1H153KV	0.015 μF	1
C20	ECRR1H104ZF	0.1 μF	1
C22	ECKR1E473ZV	0.047 μF	1
C23	AC2061G473Z5	0.047 F, 5.5 V	1
C24	ECEA0JU101	100 μF, 6.3 V	1
C26	ECRR1H104ZF	0.1 μF	1
C27, 28	ECCR1H220J	22 pF	2
C29~31	ECKR1E473ZV	0.047 μF	3
C32	ECCR1H221J	220 pF	1
C33	ECEA0JU331	330 μF, 6.3 V	1
C34	ECEA0JU470	47 μF, 6.3 V	1
C35	ECEA0JU331	330 μF, 6.3 V	1
C36	ECQG1H472KZ	0.0047 μF	1
C37	ECQG1H102KZ	0.001 μF	1
C38	ECQG1H472KZ	0.0047 μF	1
C39	ECQG1H102KZ	0.001 μF	1
C40	ECQG1H472KZ	0.0047 μF	1
C41	ECQG1H102KZ	0.001 μF	1
C42	ECQG1H472KZ	0.0047 μF	1
C43	ECQG1H102KZ	0.001 μF	1
C44	ECQG1H472KZ	0.0047 μF	1
C45	ECQG1H102KZ	0.001 μF	1
C46	ECQG1H472KZ	0.0047 μF	1
C47	ECQG1H102KZ	0.001 μF	1
C48	ECQG1H472KZ	0.0047 μF	1
C49	ECQG1H102KZ	0.001 μF	1
C50	ECQG1H472KZ	0.0047 μF	1
C51	ECQG1H102KZ	0.001 μF	1
C52	ECCR1H331J	330 pF	1
C53	ECCR1H221J	220 pF	1
C54	ECCR1H681J	680 pF	1
C56	ECQG1H472KZ	0.0047 μF	1
C57	ECQG1H102KZ	0.001 μF	1
C58	ECQG1H472KZ	0.0047 μF	1
C59	ECQG1H102KZ	0.001 μF	1
C60	ECQG1H472KZ	0.0047 μF	1
C61	ECQG1H102KZ	0.001 μF	1
C62	ECQG1H472KZ	0.0047 μF	1
C63	ECQG1H102KZ	0.001 μF	1
C64	ECQG1H472KZ	0.0047 μF	1

Ref. No.	Part No.	Description	Per/Set
C65	ECQG1H102KZ	0.001 μF	1
C66	ECQG1H472KZ	0.0047 μF	1
C67	ECQG1H102KZ	0.001 μF	1
C68	ECQG1H472KZ	0.0047 μF	1
C69	ECQG1H102KZ	0.001 μF	1
C70	ECQG1H472KZ	0.0047 μF	1
C71	ECQG1H102KZ	0.001 μF	1
C72, 73	ECCR1H681J	680 pF	2
C74, 75	ECKR1E473ZV	0.047 μF	2
C76	ECCR1H221J	220 pF	1
C77	ECEA0JU331	330 μF, 6.3 V	1
C79	ECEA0JU331	330 μF, 6.3 V	1
C82	ECEA1HU010	1 μF, 50 V	1
C86	ECKR1E473ZV	0.047 μF	1
C87	ECEA1HU010	1 μF, 50 V	1
C88	ECKR1E473ZV	0.047 μF	1
C89	ECEA1HU010	1 μF, 50 V	1
C90	ECKR1E473ZV	0.047 μF	1
C94	ECQG1H152KZ	0.0015 μF	1
C98	ECCR1H471J	470 pF	1
C99	ECQG1H222KZ	0.0022 μF	1
C100, 101	ECCR1H471J	470 pF	2
C102	ECCR1H101J	100 pF	1
C107, 108	ECCR1H471J	470 pF	2
C109	ECQG1H222KZ	0.0022 μF	1
C110	ECCR1H101J	100 pF	1
C112	ECCR1H681J	680 pF	1
C113	ECCR1H471J	470 pF	1
C114	ECCR1H151J	150 pF	1
C115	ECEA1HU010	1 μF, 50 V	1
C120, 121	ECQV1H334JZ	0.33 μF	2
C122	ECEA1HU010	1 μF, 50 V	1
C123, 124	ECCR1H151J	150 pF	2
C125	ECEA1EU100	10 μF, 25 V	1
C126, 127	ECCR1H151J	150 pF	2
C128, 129	ECEA1EU100	10 μF, 25 V	2
C130, 131	ECCR1H151J	150 pF	2
C132	ECQM1H103KV	0.01 μF	1
C133	ECQV1H104JZ	0.1 μF	1
C136	ECCR1H220J	22 pF	1
C137	ECEA1HU010	1 μF, 50 V	1
C138	ECQV1H224JZ	0.22 μF	1
C139	ECEA1CU470	47 μF, 16 V	1
C140	ECQG1H682KZ	0.0068 μF	1
C141	ECQV1H104JZ	0.1 μF	1
C142	ECQG1H102KZ	0.001 μF	1
C143	ECQG1H332KZ	0.0033 μF	1
C144, 145	ECEA1HU010	1 μF, 50 V	2
C146	ECEA1CU470	47 μF, 16 V	1
C147	ECQG1H102KZ	0.001 μF	1
C148	ECEA1EU100	10 μF, 25 V	1
C149	ECQV1H473JZ	0.047 μF	1
C150	ECCR1H220J	22 pF	1
C153	ECKR1E473ZV	0.047 μF	1
C154	ECCR1H101J	100 pF	1
C158	ECEA1HU010	1 μF, 50 V	1
C159	ECEA1HN010S	1 μF, 50 V	1
C160	ECCR1H220J	22 pF	1
C161	ECEA1HN010S	1 μF, 50 V	1
C162	ECEA0JU331	330 μF, 6.3 V	1
C163, 164	ECEA1CU101	100 μF, 16 V	2
C166, 167	ECEA1CU470	47 μF, 16 V	2
C171	ECKR1E473ZV	0.047 μF	1
C173	ECEA1CU470	47 μF, 16 V	1
C174	ECCR1H681J	680 pF	1
C175	ECCR1H331J	330 pF	1
C176	ECKR1E473ZV	0.047 μF	1
C177	ECCR1H331J	330 pF	1

} [M][MC][EZ][XL]
areas only

CPSL SIDE CONTROL PANEL CIRCUIT

Ref. No.	Part No.	Description	Per/Set
C178	ECEA1CU470	47μF, 16V	1
C179	ECCR1H681J	680pF	1
C180	ECCR1H471J	470pF	1
C181	ECQG1H222KZ	0.0022μF	1
C182	ECCR1H101J	100pF	1
C183	ECQV1H104JZ	0.1μF	1
C184	ECEA1CU470	47μF, 16V	1
C185	ECCR1H681J	680pF	1
C190	ECQV1H474JZ	0.47μF	1
C194	ECQV1H473JZ	0.047μF	1
C198	ECQG1H682KZ	0.0068μF	1
C199	ECEA0JU331	330μF, 6.3V, [M] area only	1
C200, 201	ECKR1E473ZV	0.047μF	2
C202	ECEA0JU331	330μF, 6.3V	1
C203	ECKR1E473ZV	0.047μF	1
C205, 206	ECKR1E473ZV	0.047μF	2
C208~214	ECKR1E473ZV	0.047μF	7
C216	ECQG1H472KZ	0.0047μF	1
C217	ECQG1H222KZ	0.0022μF	1
C300	ECQG1H332KZ	0.0033μF	1
C312, 313	ECKR1E473ZV	0.047μF	2
C320	ECRR1H104ZF	0.1μF	1

Ref. No.	Part No.	Description	Per/Set
INTEGRATED CIRCUITS			
IC1	MN15524PGY	1 chip 4 bit Microcomputer	1
IC2~4	SVIGM74LS07	Hex Buffers (O.C.)	3
TRANSISTORS			
Q1~4	2SA830B		4
Q5~6	2SC1047C		2
S Q7	2SA1015-GR	2SA933STRS (SUB. Part)	1
DIODES			
D3, 6~24, 27~45, 49~67, 70~87, 173, 175	MA165TA5	DIODE	78
D89~99, 102~107, 109~127, 134~148, 151~166, 168	SVDGSEL4117R	LED (Red)	68
D100, 101, 131~133, 167, 174	SVDGSEL4417G	LED (Green)	7

OSCILLATOR			
X1	EF0FC4004A3	4MHz, Ceramic Oscillator	1

SWITCHES			
S1	SSSG1011A	Transpose	1
S6~24, 27~45, 49~66	SSHG1045A	Push switch	56
S69~87	SSHG1045A	Push switch	19

VARIABLE RESISTOR			
VR1	EVD06510B24G	20KΩ B, TEMPO CONTROL	1

RESISTORS			
R1	ERDS2TJ222	2.2KΩ	2
R2~6	ERDS2TJ103	10KΩ	5
R7~10	ERDS2TJ152	1.5KΩ	4
R14	ERDS2TJ330	33Ω	1
R15~32	ERDS2TJ470	47Ω	18
R33, 34	ERDS2TJ472	4.7KΩ	2
R35	ERDS2TJ222	2.2KΩ	1
R36~39	ERDS2TJ152	1.5KΩ	4
R41~59	ERDS2TJ152	1.5KΩ	19

CAPACITORS			
C1	ECEA0JK470	47μF, 6.3V	1
C2	ECRR1H104ZF	0.1μF	1
C3	ECBA1H471KB	470pF	1

DP DRUM PARCUSSION CIRCUIT

Ref. No.	Part No.	Description	Per/Set
INTEGRATED CIRCUITS			
IC1	MN50015PGQ	Gate Array	1
IC2	MN231001PGW	1M bit Mask ROM	1
IC3	SVIGHA17008P	8 bit D-A Converter	1
IC4	SVIGMSM4051R	8-channel Multiplexer	1
IC5	SVIGM5238L	Operational Amplifier	1
COMPONENT COMBINATIONS			
Z1	EXKS14Z2073	1KΩ/2KΩ, Ladder Network	1
RESISTORS			
R4	ERDS2TJ472	4.7KΩ	1
R5	ERDS2TJ103	10KΩ	1
R6, 7	ERDS2TJ471	470Ω	2
R8	ERDS2TJ682	6.8KΩ	1
R9~11	ERDS2TJ222	2.2KΩ	3
R12	ERDS2TJ223	22KΩ	1
R14	ERDS2TJ223	22KΩ	1
R13	ERDS2TJ104	100KΩ	1
CAPACITORS			
C4	ECEA1HU010	1μF, 50V	1
C5, 6	ECKR1E473ZV	0.047μF	2
C9	ECCR1H151J	150pF	1
C10	ECKR1E473ZV	0.047μF	1
C12	ECCR1H681J	680pF	1
C13	ECCR1H680J	68pF	1
C14	ECKR1E473ZV	0.047μF	1

CPL CONTROL PANEL LEFT CIRCUIT

Ref. No.	Part No.	Description	Per/Set
INTEGRATED CIRCUITS			
IC1, 2	SVIGM74LS174	Hex D-type Flip-Flops	2
IC3	SVIGM74LS138	Decoder	1
IC4	SVIGUPD7225	LCD Driver	1
TRANSISTORS			
S Q1	2SA1015-GR	2SA933STRS (SUB. Part)	1
S Q2, 3	2SC2320LFG	2SC1310FG (SUB. Part)	2
DIODES			
D1~12	MA165TA5	Diode	12
D13~24	SVDGSEL4117R	LED (Red)	12
LCD DISPLAY			
○ LCD1	SXEG101A	LCD Display	1
SWITCHES			
S1~12	SSHG1045A	Push switch	12
RESISTORS			
R1~12	ERDS2TJ221	220Ω	12
R14	ERDS2TJ332	3.3 KΩ	1
R15	ERDS2TJ103	10 KΩ	1
R16	ERDS2TJ184	180 KΩ	1
R17, 18	ERDS2TJ472	4.7 KΩ	2
R19	ERDS2TJ104	100 KΩ	1
R20	ERDS2TJ103	10 KΩ	1
R21, 22	ERDS2TJ472	4.7 KΩ	2
CAPACITORS			
C1	ECRR1H104ZF	0.1μF	1
C2	ECEA0JK470	47μF, 6.3V	1
C3~5	ECRR1H104ZF	0.1μF	3

CP CONTROL PANEL RIGHT CIRCUIT

Ref. No.	Part No.	Description	Per/Set
INTEGRATED CIRCUITS			
IC1	SVIGM74LS138	Decoder	1
IC3	SVIGM74LS174	Hex D-type Flip-Flops	1
TRANSISTOR			
S Q1	2SA1015-GR	2SA933STRS (SUB. Part)	1
DIODES			
D13~16	MA165TA5	Diode	4
D19, 23~25	SVDGSEL4417G	LED (Green)	4
SWITCHES			
S1~4	SSHG1045A	Push switch	4

Ref. No.	Part No.	Description	Per/Set
RESISTORS			
R1	ERDS2TJ332	3.3 KΩ	1
R2	ERDS2TJ103	10 KΩ	1
R9~12	ERDS2TJ221	220Ω	4
R19	ERDS2TJ221	220Ω	1
CAPACITORS			
C1, 2	ECRR1H104ZF	0.1μF	2

AS AMP & POWER SUPPLY CIRCUIT

Ref. No.	Part No.	Description	Per/Set
INTEGRATED CIRCUITS			
IC1	SVIGM5F7815	Voltage Regulator	1
IC2	SVIGM5F7915	Voltage Regulator	1
IC3	SVIGM5291P	Switching Regulator	1
TRANSISTORS			
S Q1~3, 5, 6, 11	2SC2320LFG	2SC1310FG (SUB. Part)	6
Q4	2SB953A		1
Q7	2SA1123S		1
Q8	2SC1815GR		1
Q9	2SD1277A		1
Q10	2SB951A		1
DIODES			
D1, 2	△ SVDGERA1502Y	Rectifier	2
D3~6	△ SVDGS3V20-15	Rectifier	4
D7~9	MA165TA5		3
D10	SVDGRK14S		1
D11	MA4062	Zener, 6.2V	1
D12	MA2062LF	Zener, 6.2V	1
COILS & LINE FILTER			
L1	△ SLTGLF3	Line Filter	1
L3	SLCG1A121T	Coil	1
JACK			
JK1	△ SJVD0203B	AC Inlet	1
SWITCH			
S1	△ SSRG100A	Voltage Selector, Except for [EN][EZ][M][MC] areas	1
RELAY			
RL1	SSYGMR30112	Relay	1
FUSES			
F1, 2	△ XBA1C40NU100	4A, 125V, [M][MC] areas	2
F2	△ XBA2C16TB0	T 1.6A, 250V	} [EN][EZ] areas
F4	△ XBA2C40TB0	T 4A, 250V	
F1	△ XBA2C31TB0	T 3.15A, 250V	1
F2, 3	△ XBA2C16TB0	T 1.6A, 250V	} others
F4	△ XBA2C40TB0	T 4A, 250V	

HP HEADPHONES CIRCUIT

Ref. No.	Part No.	Description	Per/Set
AC INLET COVER			
XL XR Δ	SJS9334A	AC Inlet Cover, [XL][XR] areas	1
Δ	SJS9231A	AC Inlet Cover, other areas	1

RESISTORS			
R1~3	ERDS2TJ103	10 K Ω	3
R4	ERDS2TJ472	4.7 K Ω	1
R5	ERDS2TJ471	470 Ω	1
R6, 7	ERDS2TJ473	47 K Ω	2
R8	ERDS2TJ104	100 K Ω	1
R9	ERDS2TJ472	4.7 K Ω	1
R10	ERDS2TJ473	47 K Ω	1
R11	ERDS2TJ222	2.2 K Ω	1
R12, 13	ERDS2TJ154	150 K Ω	2
R14	Δ ERD25FVJ680	68 Ω , 1/4W, Flame-Proof	1
R15	Δ ERX1ANJPR22S	0.22 Ω , 1W, Flame-Proof	1
R16	ERDS2TJ101	100 Ω	1
R17	ERG1ANJP471S	470 Ω , 1W, Flame-Proof	1
R18	ERDS2TJ332	3.3 K Ω	1
R19	ERDS2TJ102	1 K Ω	1
R21	ERDS2TJ103	10 K Ω	1
R22	ERDS2TJ332	3.3 K Ω	1
R23	ERDS2TJ102	1 K Ω	1
R24	ERDS2TJ472	4.7 K Ω	1
R25	ERDS2TJ103	10 K Ω	1
R26	ERDS2TJ152	1.5 K Ω	1
R27	ERDS2TJ223	22 K Ω	1
R28	ERDS2TJ682	6.8 K Ω	1
R29	ERDS2TJ153	15 K Ω	1
R30	ERDS2TJ472	4.7 K Ω	1
R31, 32	ERDS2TJ222	2.2 K Ω	2
R33, 34	Δ ERX2ANJPR22S	0.22 Ω , 2W, Flame-Proof	2
R35	Δ ERD50FJ6R8	6.8 Ω , 1/2W, Flame-Proof	1
R36	ERDS2TJ103	10 K Ω	1
R37	Δ ERQ14AJ2R0P	2 Ω , 1/4W, Fuse Type	1

CAPACITORS			
C1	Δ ECKCVA1472MF	4700 pF, 250V, Line-Capacitor	1
C2	Δ ECQU2A104MN	0.1 μ F, 250V, Across-the Line-Capacitor	1
C3	EZ XL Δ ECQE2A104MW	0.1 μ F, 250V, [EZ][XL][XR][M][MC] areas	1
C4, 5	ECEA1VU102	1000 μ F, 35V	2
C8~10	ECEA1VU100	10 μ F, 35V	3
C11	ECCR1H471J	470 pF	1
C12	ECEA0JU222	2200 μ F, 6.3V	1
C14	ECEA1HN010S	1 μ F, 50V	1
C16	ECEA0JU470	47 μ F, 6.3V	1
C17	ECCR1H101J	100 pF	1
C18	ECEA1VU100	10 μ F, 35V	1
C19	ECCR1H221J	220 pF	1
C20	ECQV1H473JZ	0.047 μ F	1
C21	ECEA50Y3R3	3.3 μ F, 50V	1
C22	ECEA50Y6R8	6.8 μ F, 50V	1
C23	ECEA1HUR47	0.47 μ F, 50V	1
C24	ECEA1EU100	10 μ F, 25V	1
C25	ECEA1CU470	47 μ F, 16V	1
C26	ECQG1H102KZ	0.001 μ F	1

Ref. No.	Part No.	Description	Per/Set
JACK			
JK1	SJJG100A	Jack	1
RESISTORS			
R1, R2	Δ ERD50FJ681	680 Ω , 1/2W, Flame-Proof	2

MKB MANUAL KEYBOARD CIRCUIT

Ref. No.	Part No.	Description	Per/Set
INTEGRATED CIRCUIT			
IC1	SVIGM74LS138	Decoder	1
DIODES			
S D1~44	MA162A	MA150IR	44
SWITCHES			
S1~7, 38~44	SSPG7001A	Rubber Switch (7 pcs. on one)	2
S8~37	SSPG6001A	Rubber Switch (6 pcs. on one)	5
CAPACITORS			
C1	ECKR1E473ZV	0.047 μ F	1
C2	ECEA0JK470	47 μ F, 6.3V	1

PKB PEDAL KEYBOARD CIRCUIT

Ref. No.	Part No.	Description	Per/Set
TRANSISTORS			
S Q1, 2, 4	2SA1015-GR	2SA933STRS (SUB. Part)	3
S Q5~17	2SC2320LFG	2SC1310FG (SUB. Part)	13
SWITCHES			
S1~13	SHGG50A	Rubber Switch (5 pcs. on one)	3
RESISTORS			
R1, 2	ER0S2CKF4700	470 Ω , $\pm 1\%$	2
R3	ERDS2TJ472	4.7 K Ω	1
R5	ER0S2CKF4700	470 Ω , $\pm 1\%$	1
R7	ERDS2TJ472	4.7 K Ω	1
R8	ERDS2TJ103	10 K Ω	1
R9	ERDS2TJ472	4.7 K Ω	1
R10	ERDS2TJ103	10 K Ω	1
R11	ERDS2TJ472	4.7 K Ω	1
R12	ERDS2TJ103	10 K Ω	1
R13	ERDS2TJ472	4.7 K Ω	1
R14	ERDS2TJ103	10 K Ω	1
R15	ERDS2TJ472	4.7 K Ω	1
R16	ERDS2TJ103	10 K Ω	1
R17	ERDS2TJ472	4.7 K Ω	1

■ WIRING PARTS

Ref. No.	Part No.	Description	Per/Set
R18	ERDS2TJ103	10KΩ	1
R19	ERDS2TJ472	4.7KΩ	1
R20	ERDS2TJ103	10KΩ	1
R21	ERDS2TJ472	4.7KΩ	1
R22	ERDS2TJ103	10KΩ	1
R23~29	ER0S2CKF4700	470Ω, ±1%	7
R30	ER0S2CKF1001	1KΩ, ±1%	1
R32	ERDS2TJ472	4.7KΩ	1
R33	ERDS2TJ103	10KΩ	1
R34	ERDS2TJ472	4.7KΩ	1
R35	ERDS2TJ103	10KΩ	1
R36	ERDS2TJ472	4.7KΩ	1
R37	ERDS2TJ103	10KΩ	1
R38	ERDS2TJ472	4.7KΩ	1
R39	ERDS2TJ103	10KΩ	1
R40	ERDS2TJ472	4.7KΩ	1
R41	ERDS2TJ103	10KΩ	1
R42~45	ER0S2CKF4700	470Ω, ±1%	4
R46	ER0S2CKF2201	2.2KΩ, ±1%	1
R51	ERDS2TJ472	4.7KΩ	1

Ref. No.	Part No.	Description	Per/Set
W1	SWKG1077SSA	Connector, with Wire	1
W2	SWKG1336SSA	Connector, with Wire	1
W3	SWKG0876SSB	Connector, with Wire	1
W4	SWKG06103SSA	Connector, with Wire	1
○ W5	SWKG1349SSA	Connector, with Wire	1
○ W6	SWKG1350SSA	Connector, with Wire	1
○ W7	SWKG1422SSA	Connector, with Wire	1
○ W8	SWKG0715ZB	Connector, with Wire	1
W9	SWKG1337SSA	Connector, with Wire	1
○ W10	SWKG04157SSA	Connector, with Wire	1
W11	SWKG0326LTA	Connector, with Wire	1
○ W12	SWKG04158LSA	Connector, with Wire	1
○ W13	SWKG04156LSB	Connector, with Wire	1
○ W14	SWKG1088LSA	Connector, with Wire	1
○ W15	SWKG04155ZB	Connector, with Wire	1
○ W16	SWKG06134LSA	Connector, with Wire	1
○ W17	SWKG03124ZA	Connector, with Wire	1
○ W18	SWKG0247ZB	Connector, with Wire	1

EXP EXP CIRCUIT

Ref. No.	Part No.	Description	Per/Set
CDS			
CS1	SVEG5	Light Sensitive Device	1

REPLACEMENT PARTS LIST.....Cabinet and Chassis Parts

Notes:

1. Important safety notice

Components identified by Δ mark have special characteristics important for safety. When replacing any of these components, use only manufacturer's specified parts.

2. ○ mark are new parts.

3. For part No. with area mark, check the area when placing an order.

■ CABINET & CHASSIS PARTS


Ref. No.	Part No.	Description	Per/Set
SWITCH			
S1 Δ	SSHG1050A	Power Switch	1
TRANSFORMER			
○ T1 Δ	SLTG5M48	Power Transformer	1
○ T1 Δ	SLTG5M49	Power Transformer	1
AC POWER CORD & PLUG			
PC1 Δ	SJAG39	AC Cord	1
PC1 Δ	SJAG61	AC Cord	1

Ref. No.	Part No.	Description	Per/Set
PC1 Δ	SJAG62	AC Cord	1
PC1 Δ	SJAG41	AC Cord, others	1
PC2 Δ	SJP5213-1	Attachment Plug, [X] area	1
PC3 Δ	SJPG1350A	Attachment Plug, [XD] area	1
SPEAKER			
SP2	EAS15S06A	6×13cm, 16Ω	1
SP3	EAS65PH31A	6.5cm, 8Ω	1

Ref. No.	Part No.	Description	Per/Set
CABINET			
1	[EX25L] SKGG1B130A	Music Rack	1
2	[EX25L] SHGG6261A	Rubber	1
3	[EX25L] SYWGA1060B	Upper Control Panel	1
4	[EX25] SYWGA1060A1	Upper Control Panel	1
5	SGUG90A	Display Cover Panel	1
6	SGWG8230B	Lower Control Panel, Left	1
7	SGWS8220D	Lower Control Panel, Right	1
8	SHSG3940A	Felt	1
9	SHRG9920A	Spacer	1
10	SHSG3950A	Felt	1
11	SKEG1240A	Cover	1
12	SUWG2980A	Bracket	1
13	SHSG5820A	Felt	1
14	SHSG5830A	Felt	1
15	SGXG3210A	Ornament, Keyboard	1
15-1	[EX25] SKZG8520A	Keyboard Cover Ass'y	1
15-2	[EX25] SBHG190A	Hinge	3
15-3	[EX25] SBHG200A	Hinge	3
16	[EX25] SKHG80A	Grip	2
17	[EX25] SBHG210A	Hinge	2
17	[EX25L] SKZG7831A	Rear Board (Upper)	1
18	[EX25L] SKZG7830A	Rear Board (Upper)	1
18	XL XR SJS9334A	AC Inlet Caver	1
18	SJS9231A	AC Inlet Caver	1
19	SMKG3470A	Jack Panel	1
20	EN EL SMKG3480A	AC Panel	1
20	EZ M MC SMKG3481A	AC Panel, others	1
21	SMKG3490A	Headphone Jack Panel	1
22	SHSG2870A	Felt	1
23	SGXG3200A	Ornament, Front	1
24	SGBG160A	Technics Badge	1
25	SGKG980A	Headphone label	1
KNOBS, BUTTONS			
26	SBCG110B	Button (Power Switch)	1
27	SBNG7050A	KNOB (TEMPO, TRANSPOSE)	2
28	SBCG1330A	Button (UPPER SOLO)	1
29	SBCG1340A	Button (UPPER POLY)	1
30	SBCG1350A	Button (CELESTE, TAB TREMOLO)	1
31	SBCG1360A	Button (BASS)	1
32	SBCG1370A	Button (SUSTAIN)	1
33	SBCG1380A	Button (LOWER POLY)	1
34	SBCG1390A	Button (VSC, ORCHESTRAL CONDUCTOR)	1
35	SBCG1400A	Button (RHYTHM)	1
36	SBCG1410A	Button (MAIN VOL)	1
37	SBCG1420A	Button (FILL IN & INTRO, ENDING)	1
38	SBCG1430A	Button (PLAY MODE)	1
39	SBCG1440A	Button (UPPER TAB VOICES)	1
40	SBCG1450A	Button (LOWER TAB VOICES)	1
41	SBCG1480A	Button (PLAY SEQUENCER)	1
MANUAL KEYBOARD			
42	STBG1150A	Wite Key (Top Octave C Key)	2
43	STBG1120A	Wite Key (B & E Key)	14
44	STBG1110A	Wite Key (D Key)	6
45	STBG1100A	Wite Key (C & F Key)	14
46	STBG1140A	Wite Key (A Key)	8

Ref. No.	Part No.	Description	Per/Set
47	STBG1130A	Wite Key (G Key)	8
48	STBG2070A	Black Key	36
49	SUSG270A	Spring	88
50	SHSG1931A	Felt	4
51	SHGG9050A	Key Guide Rubber	88
52	SSPG7001A	Rubber Switch (7 pcs. on one)	4
53	SSPG6001A	Rubber Switch (6 pcs. on one)	10
SCREWS & WASHERS			
N1	XTB4+12A	Screw	43
N2	XTW3+10Q	Screw	37
N3	XTS3+6B	Screw	2
N4	XYN4+F40	Screw with Washer	1
N5	XYN4+F10	Screw with Washer	1
N6	SNEG740A	Screw	2
N7	XTB3+5C	Screw	16
N8	XTT4+10A	Screw	3
N9	XYN5+C10	Screw with Washer	1
N10	XYN3+F6FZ	Screw with Washer	4
N11	XTB3+5FFZ	Screw	24
N12	XTB3+8GFZ	Screw	4
N13	XTW3+10JFZ	Screw	8
N14	XYN4+F10FZ	Screw with Washer	7
N15	XTT4+16AFZ	Screw	6
N16	XTB35+12A	Screw	10
N17	SNEG1241A	Screw	4
N18	XTW3+8JFZ	Screw	3
N19	XTB35+8A	Screw	4
N20	XTT4+30A	Screw	2
N21	XTB35+10A	Screw	8
N22	XYN4+F12	Screw with Washer	4
N23	SNEG2560A	Screw with Washer	4
N24	SNEG770A	Washer	1
N25	XNS12FZ	Nut	1
N26	SNEG150A	Washer	9
N27	XWA5B	Washer	2
N28	XSN5+85FVC	Screw	2
N29	XYN5+C25FVC	Screw with Washer	7
N30	XTB35+20A	Screw	4
N31	XTB3+8BFVC	Screw	2
N32	XTT35+10AFVC	Screw	5
N33	XTW3+10T	Screw	24

EXPLODED VIEWS OF CABINET






■ STAND & BENCH

Ref. No.	Part No.	Description	Per/Set
SPEAKER			
SP1	EAS20PL255A	20 cm, 4Ω	1
STAND			
○ 1	SKFG1291A	Rear Board	1
○ 2	SKZG9420B	Speaker Box	1
○ 3	SWKG03124ZA	Wire with Connector	1
○ 4	SHRG47390	Sponge	1
5	SHRG1110A	Cord Clamper	1
6	SHRG1120A	Cord Clamper	1
○ 7	SKSG2790A	Left Plank Ass'y	1
7-1	[SHRG9620A	Cord Clamper	2
○ 8	SKSG2800A	Right Plank Ass'y	1
8-1	[SHRG9620A	Cord Clamper	2
○ 9	SWKG0715ZB	Wire with Connector	1
9-1	[SHRG1160A	Cord Clamper	1
○ 10	SKFG2530A	Rear Board	1
○ 11	SHSG6140A	Felt	1
○ 12	SKZGE300A	Pedal Box Ass'y	1
12-1	[SHSG3170A	Felt	1
12-2	[SKLA7-2	Foot	1
13	SHSG6030A	Felt	1
○ 14	SKLG280A	Leg, Except for [M] area	1
○ 14	M SKLG281A	Leg, [M] area only	1
○ 15	SKLG290A	Leg, Except for [M] area	1
○ 15	M SKLG291A	Leg, [M] area only	1
16	SXVG5110A	Expression Pedal Ass'y	1
16-1	[SSHG14	Foot Switch	1
16-2	[XAMR55P	Lamp	1
16-3	[RJS205ZA	Socket	1
17	SHGG50A	Rubber Switch (5 pcs. on one)	3
18	SHSG1600B	Felt	1
19	STBG4011A	Key Guide	1
20	SHSG1460A	Felt (Key Guide)	13
21	STBG1091C	White Key	8
22	STBG2052A	Black Key	5
23	SUSG180A	Spring	13
24	SHGG8130A	Rubber	13
25	SHRG9240A	Spacer	13
BENCH			
26	SKPG920A	Top Cover	1
27	SKZG7680A	Crossboard	1
28	SKSG1860A	Plank	2
29	SHRG2060C	Foot	4
30	SNEG1760B	Cap	6

Ref. No.	Part No.	Description	Per/Set
SCREWS & WASHERS			
○ N1	XTT35+30AFZ	Screw	11
N2	XYN3+F30	Screw with Washer	2
N3	SNE499-1	Nut	4
○ N4	SNEG2560A	Screw with Washer	6
N5	XST4+20FZ	Screw	4
N6	XYN5+F16	Screw with Washer	4
N7	XYN4+F20FZ	Screw with Washer	4
N8	XTT4+16A	Screw	8
N9	XYN4+F30	Screw with Washer	6
N10	XTB35+16A	Screw	1
N11	XTT4+16AFZ	Screw	2
N12	XTN26+6B	Screw	1
N13	XTB3+6B	Screw	11
N14	XNG5BS	Nut	13
N15	XTW3+8J	Screw	3
N16	SNEG360A	Bolt	13
N17	SNEG1720B	Bolt	6
N18	SNEG1710A	Nut	6
N19	XTB3+25A	Screw	8

PACKING



PACKING PARTS (Except for [M] area) i)

PACKING PARTS (Products for [M] area)

Ref. No.	Part No.	Description	Per/Set
○ 1	SPNG2068	Pad	1
○ 2	SPNG5809B	Cushion Pad	1
○ 3	SPNG5810B	Cushion Pad	1
○ 4	SPNG2071A	Pad	1
○ 5	SPNG2072A	Music Rack Case	1
○ 6	SPNG2070A	Planks Case	1
○ 7	SPNG5806A	Cushion Pad	1
○ 8	SPNG5807A	Cushion Pad	1
○ 9	SPNG5808A	Cushion Pad	1
○ 10	SPNG3120A	Pad	2
○ 11 [EX25]	SPNG2064A	Packing Case, EX25 only	1
○ 11 [EX25L]	SPNG2060A	Packing Case, EX25L only	1
○ 12	SPHG1630A	Polyethylene Bag	2
○ 13	SPHG1110A	Polyethylene Bag	1
○ 14	SPHG280A	Protection Sheet	1
○ 15 [EX25]	SPHG2260A	Protection Sheet, EX25 only	1
○ 16	SPHG1641A	Polyethylene Bag	3
○ 17	SPSG40A	Band	2
○ 18	SPNG2073A	Pad	2
○ 19	SPNG1784A	Packing Case, Bench	1
INSTRUCTION BOOK			
○ 20	EN SQFGA1360	Instruction Book, [EN] only	1
○ 20	SQFGA1390	Instruction Book	1

Ref. No.	Part No.	Description	Per/Set
○ 1	SPNG2069	Pad	1
○ 2	SPNG5809B	Cushion Pad	1
○ 3	SPNG5810B	Cushion Pad	1
○ 4	SPNG2071A	Pad	1
○ 5	SPNG2072A	Music Rack Case	1
○ 6	SPNG2070A	Planks Case	1
○ 7	SPNG5806A	Cushion Pad	1
○ 8	SPNG5807A	Cushion Pad	1
○ 9	SPNG5808A	Cushion Pad	1
○ 10	SPNG5845A	Pad	2
○ 11	SPNG2062A	Packing Case	1
○ 12	SPHG1630A	Polyethylene Bag	2
○ 13	SPHG1110A	Polyethylene Bag	1
○ 14	SPHG280A	Protection Sheet	1
○ 16	SPHG1641A	Polyethylene Bag	3
○ 17	SPSG40A	Band	2
INSTRUCTION BOOK			
○ 20	SQFGA1381	Instruction Book	1